


# **M8i** | **Operation manual**



## Introduction

Thank you for choosing a high-quality product “MADE IN GERMANY” from TWAUDIÖ.

The M8i is the installation version of the M8, one of the most popular TWAUDIÖ products. The M8i takes the same uncompromising acoustic design of the M8 (8“ LF-driver, 1“ compression driver and rotatable 90° x 60° horn) and places it in the i-series installation specific enclosure.

The phase-aligned and frequency corrected passive crossover allows the M8i to be driven even by standard linear amplifier without DSP presets. For extended fullrange use, or in combination with TWAUDIÖ subwoofers, there are dedicated presets available for Powersoft and Lab.gruppen amplifier platforms.

The M8i allows delivery of uncompromising audio in an architecturally discrete package.

If you lend your product to another party, inform that party of the safety-related operating procedures and hand over this assembly guide. If you require additional copies of this manual, you can obtain them free of charge from TWAUDIÖ or download them from [www.twaudio.de](http://www.twaudio.de)

### Instructions in this user manual

Strictly adhere to the instructions contained in this operating manual that are marked as follows:



This symbol in combination with the signal word “Warning” identifies a potentially hazardous situation. Failure to comply with this safety instruction can lead to serious injury or even death.



This symbol in combination with the signal word “Warning” identifies a potentially hazardous situation for persons with a pacemaker. Failure to comply with this safety instruction can lead to serious injury or even death.



This symbol in combination with the signal word “Caution” identifies a potentially hazardous situation. Failure to comply with this safety instruction can lead to light or moderate injury.



This symbol in combination with the signal word “Note” identifies a potentially hazardous situation. Failure to comply with this safety instruction can lead to product damage.



This symbol in combination with the signal word “Tip” identifies additional information or notes that will simplify working with TW AUDIÖ products on the basis of practical experience.

**Notes on the products****Read manual  
before use!**

Before using the device, carefully read the operating manual and keep it with the M8i loudspeaker.

**General information**

Operation manual: OM-M8i  
Version 1.0 en, 11/2018  
© by TWAUDIÖ 2018; all rights reserved.

All information contained in this operating manual was correct to the best of our knowledge at the time of printing.

Quality warranties or assurance of suitability for a certain type of use based on the technical specifications, dimensions and weights are not granted by TWAUDIÖ.

TWAUDIÖ also shall not assume liability for any secondary damage (property damage and/or personal injury) nor for the failure to comply with this operating manual!

TWAUDIÖ reserves the right to update this document based on recent developments.

TWAUDIÖ GmbH  
Osterholzallee 140  
71636 Ludwigsburg  
Germany

Phone : + 49 (0) 71 41-48 89 89 0  
Fax: + 49 (0) 71 41-48 89 89 99  
E-Mail: [info@twaudio.de](mailto:info@twaudio.de)  
WWW: [www.twaudio.de](http://www.twaudio.de)

## Content

1. Safety   Intended use .....	5
2. Overview .....	7
2.1 Components .....	7
3. Technical specifications .....	8
3.1 Data sheet.....	8
3.2 Connection diagram .....	8
4. Commissioning.....	9
4.1 Setup .....	9
4.2 M6 and M10 threaded inserts.....	9
4.3 Rotating the HF horn .....	10
4.4 Connection options .....	10
4.5 Operation .....	11
4.6 Connecting the cable.....	11
5. Transport and Storage.....	12
6. CE Conformity Declaration.....	12
7. Disposal .....	13

## 1. Safety | Intended use

Please adhere to the following safety instructions to avoid risks when operating loudspeakers.

The M8i loudspeaker was developed for use in professional sound systems. The loudspeaker may only be used by trained and qualified personnel.

Note the operating modes described in this operating manual. Other uses are not permissible.

Damage caused by improper use is not covered by TWAUDIÖ.



Loudspeakers generate an electromagnetic field. Persons with pacemakers are not permitted to remain in the immediate vicinity of loudspeakers as the electromagnetic fields can cause pacemakers to malfunction.



Ensure that the units are in a stable position and are firmly attached. A falling loudspeaker can result in serious personal injury and property damage.

When using and assembling TWAUDIÖ loudspeakers, only use materials specified by TWAUDIÖ. These tasks must be performed by qualified personnel. Adhere to the applicable safety regulations.



When setting up loudspeakers, ensure that they are not exposed to the following ambient conditions:

- direct sunlight
- Humidity
- Jolting
- Dust



Keep away from the immediate vicinity of loudspeakers that are operated at high sound pressure levels. These loudspeaker systems are capable of endangering your health. Sound levels beginning as low as approximately 90 dB SPL can lead to long-term hearing impairment.



Avoid:

- Feedback
- Distorted signals (clipping) and
- Peaks resulting from switching on devices, plugging in devices or unplugging devices during operation.

Such signals can lead to loudspeaker overload and ultimately to loudspeaker failure.



Ensure that the loudspeaker is not exposed to permanent thermal overloads. Thermal overloads may cause a fire and result in serious personal injury and property damage.

Note that TWAUDIÖ does not provide a warranty for damage that can be attributed to this type of overload and therefore cannot be held liable for any secondary damage.




A permanent magnetic field is present in the immediate vicinity of loudspeakers. Ensure that objects which react sensitively to magnetic fields are not located in the immediate vicinity of the loudspeaker. In particular, this applies to magnetic storage media, magnetic stripe cards such as debit cards and CRT displays. A distance of approximately one meter is sufficient to avoid damage.



Check loudspeakers and accessory parts regularly for visible wear. This is essential to ensure continuing fault-free operation. Worn parts should be replaced immediately. Spare parts are available from TWAUDIÖ.

## 2. Overview

### 2.1 Components



**Figure 2.1 - Overview**

1. Front grill
2. 15 mm Multiplex enclosure - Warnex textured paint surface
3. M10 threaded insert for attaching accessories (4 pieces)
4. Rotatable horn with 1" compression driver
5. 8" cone driver
6. M6 threaded insert for attaching accessories (6 pieces)
7. Type label
8. Standard i-series screw terminal

### 3. Technical specifications

#### 3.1 Data sheet

Drivers	1x 8" LF / 1x 1,0" HF
Frequency response	66 - 20000 Hz
Power handling (program/Peak)	400 / 800 W
Impedance	8 $\Omega$
Coverage (h x v)	90° x 60° rotatable
Max. SPL / 1m	124 dB
Dimensions (h x w x d)	440 x 240 x 240 mm [17,32 x 9,45 x 9,45 in]
Weight	10,3 kg [22,708 lbs]
Surface	Warnex textured paint

#### 3.2 Connection diagram




Figure 3.2 - Connection diagram



## 4. Commissioning

### 4.1 Setup

The M8i loudspeaker is designed for hanging, vertical and horizontal operation. TWAUDIÖ provides a wide range of accessories to securely attach the loudspeaker.



Make sure that all system structures are located on a firm, level surface and that the surface can bear the total weight!



Make sure the speakers are securely fastened to prevent personal injury and property damage.



TWAUDIÖ recommends using only the accessories specified by TWAUDIÖ for securing and mounting loudspeakers.

### 4.2 M6 and M10 threaded inserts

Before fitting the accessories follow the subsequent steps:

1. To remove the countersunk screws remove the texture paint by using a cutter knife. Avoid damaging the surrounding paint to prevent chipping.
2. Remove for your application required countersunk screws. Use a hexalobular key with the size of TX30 or TX50.



3. Please note that once the countersunk screws are removed, water and moisture may enter into the enclosure.



4. For the M8i loudspeaker M6 and M10 threaded inserts, various TWAUDIÖ accessories can be mounted. For each product refer to the instructions.
5. Note that the load capacity is limited to a single speaker.

## 4.3 Rotating the HF horn

With the factory default orientation of the M8i loudspeaker horn, the horizontal coverage is 90° and the vertical coverage is 60°. In some situations, it may be advantageous to change the high frequency dispersion pattern. To adjust the dispersion pattern, the M8i loudspeaker's HF horn can be rotated. Proceed as follows:

1. Place the M8i loudspeaker on its back, with the speaker grille facing up. Make sure to place the speaker on a clean, non-slippery surface.
2. To remove the front grill, a 3 mm Allen key is required. Loosen the two mounting screws at the top and bottom of the speaker cabinet.
3. Loosen the four screws on the horn using a 3 mm Allen key. Pull the horn with the compression driver up and out of the speaker cabinet.
4. Check the seal between housing and horn for correct fit.
5. Carefully turn the horn by 90° and re-insert the horn with the driver back into the recess. Screw it to the housing and apply medium-strength thread-locking fluid.
6. Attach the grill using the screws provided.

## 4.4 Connection options

The M8i loudspeaker is equipped as standard with the i-series screw terminal.



### NOTE

As options there can be mounted a panel with cable gland (CG-option) or a panel with two built-in speakON® jacks (SO-option).

Furthermore, a blind cover option is available.

All connection options are only available in black colour.



### NOTE

More information about the different connection options can be found in the respective operating instructions in the download area on the homepage of TWAUDIO.

#### 4.5 Operation

M(i)series loudspeakers can be operated on standard linear amplifiers. For optimal performance, we recommend using the system amplifiers and presets provided by TWAUDIÖ.



Before connecting the loudspeaker to the amplifier, ensure that the right preset has been loaded.

Using the wrong preset or a preset not provided by TWAUDIÖ preset can destroy the speaker.



Make sure that the amplifier's specifications meet the requirements. Using an amplifier that doesn't meet the specifications can destroy the loudspeaker.

Please note the technical data in section 3.1 on page 8.

#### 4.6 Connecting the cable

To create a cable connection with an amplifier rack from TWAUDIÖ, proceed as follows.



Ensure that the cable cross sectional area is sufficient (at least 1.5 mm<sup>2</sup>) to avoid power losses. TW AUDiÖ recommends using the loudspeaker cables available from TWAUDIÖ.

When connecting the cables to the loudspeaker, ensure that polarity (+/-) and pin assignment (1/2) are correct. Incorrect connection can lead to a significant change in the loudspeaker's sound characteristics and may damage the driver.

The pin connections of the M8iloudspeaker can be found in section 3.2 ("Connection diagram") on page 8.

The internal wiring of the M8iloudspeaker allows for parallel connection of multiple loudspeaker units.

Please note that parallel connections will decrease the total impedance of your loudspeaker configuration.

The total impedance and the resulting power of the speaker configuration must match the output power of the amplifier.

## 5. Transport and Storage



### NOTE

Ensure that the front grill of the loudspeaker is not damaged during transport and storage. Moisture can penetrate exposed wood surfaces and cause the wood to swell. A bent or broken front grill will no longer adequately protect the sensitive driver membranes.

In addition, larger dust deposits can significantly affect the functionality of a speaker membrane. This is why the product should be transported and stored in a safe, careful, dry and largely dust-free manner.

## 6. CE Conformity Declaration

Copy and translation of the original CE Conformity Declaration:



We hereby declare that the below-referenced components by virtue of their design and construction, and in the configuration placed on the market by us, satisfy the safety and health requirements of the applicable EC directives. This declaration becomes invalid in case of modifications that have not been approved by us.

### **This declaration applies to the following components**

- M8i

as well as all model variants based on these, provided that they correspond to the original factory models and have not been technically modified in any way.

### **Applicable directives:**

- 2001/95/EG
- 2011/65/EU

### **Applicable national standards and technical specifications:**

- DIN EN 18800
- DIN EN ISO 12100
- DGUV Vorschrift 17 und 18
- EN 50581: 2013-02

Ludwigburg, Germany, April 1st, 2018

Tobias Wüstner

## 7. Disposal

It is prohibited to dispose of used electrical equipment with household refuse.



All TWAUDIÖ GmbH products are so-called B2B-products. This means that they are sold by a commercial business to a commercial business. TWAUDIÖ products that bear the trash can symbol shown here may only be disposed of by TWAUDIÖ.

The loudspeaker owner is legally responsible for proper disposal of used devices that do not bear this symbol. This pertains to all products delivered prior to March 29, 2010. Nevertheless, TWAUDIÖ will also be happy to assist you in this case.

If you have any question regarding the disposal of used devices, please contact us under the following telephone number:

+49 (0) 71 41 - 48 89 89 0

Thus, TWAUDIÖ is in strict compliance with the Waste Electrical and Electronic Equipment Directive (2012/19/EU) for the protection of our environment.

TWAUDIÖ is registered under the following WEEE-reg.-no. with the German National Register EAR as a B2B-manufacturer and distributor of electrical devices:

**DE54488702**

In countries outside of the European Union, comply with local regulations.

TWAUDIÖ GmbH  
Osterholzallee 140  
71636 Ludwigsburg  
Germany

Phone : + 49 (0) 71 41-48 89 89 0  
Fax: + 49 (0) 71 41-48 89 89 99  
E-Mail: [info@twaudio.de](mailto:info@twaudio.de)  
WWW: [www.twaudio.de](http://www.twaudio.de)